# AudioSource®

## S3D60

Basic Sound Bar Installation
TV & Cable Box using Component Video and Digital Audio (Optical / Toslink)

TV Input / Output Section

INPUT

Component Video	Component Video	S VIDEO	Composite Video	Composite Video
Y	Y			
Pᵦ	Pᵦ		L	L
Pᵣ	Pᵣ		R	R
L	L	L		
R	R	R		

HDMI 1 HDMI 2 DIGITAL AUDIO Analog Audio L R

OUTPUT

Component Video	S VIDEO	Composite Video
Y	Y	
Pᵦ		L
Pᵣ	L	R
L	R	
R		

HDMI 1 HDMI 2 DIGITAL AUDIO Analog Audio L R

Cable Box Ouput Section

OUTPUT

Component Video	S VIDEO	Composite Video
Y	Y	
Pᵦ		L
Pᵣ	L	R
L	R	
R		

HDMI 1 HDMI 2 DIGITAL AUDIO Analog Audio L R

---

1 Connect the Video OUTPUT of the Cable Box to the Video INPUT of the TV using a Component Video Cable

2 Connect the Digital Audio OUTPUT of the Cable Box to the Optical INPUT of the S3D60 using a Optical Cable

3 Using the source button on the front panel of the S3D60 select Optical Input

---

S3D60 Input / Output Section

Rear Panel

AUX IN   RCA IN   LINE OUT
L   L
R   R
DC IN   OPTICAL

Front Panel

S3D60 3D Sound Bar

AUX RCA OPTICAL   MOVIE NORMAL MUSIC
SOURCE   MODE   sonic emotion 3D SOUND

Optical Cable

Component Video

blue green red

blue green red

blue green red